

DISPLAY



ICONS

01. Current mode	05. Watering setting	09. Operating
02. Setting mode	06. Run time	10. <input checked="" type="checkbox"/> On
03. Set the current time	07. Off time	11. <input checked="" type="checkbox"/> Off
04. Cycles	08. Battery	

Instructions for #549 Mist Timer II:

Features include: Solar Panel for battery charging, rain sensor and will time in seconds with up to 9 different programable programs. Install 2-AA Ni-MH rechargeable batteries (High quality alkaline batteries may be used, but are not rechargeable with the solar panel). New rechargeable batteries usually need charging before use.

Either fully charge your batteries or place the timer in the sun for 3 days before programming. To re-set the timer, remove batteries then re-install.

Inlet: Female Hose Threads. Outlet: Male Hose Threads

<p>Rain Delay The rain sensor is the 2 contacts on the top, next to the solar panel. The timer will turn off when these contacts get wet, and when drip will resume at the next scheduled program. If you do not wish to have this function, a dab of silicone on the contacts will stop the rain sensor from functioning.</p>	<p>Trouble Shooting *Do not overlap run times as this will cause the program not to function. *Be sure the program is turned ON (See B). *Be sure you have AM/PM set correctly. *When setting a time to come on that's earlier than the existing time, the timer will come on your set time the following day.</p>
<p>*Battery low power: If battery power is low, LCD will display . *If there's no activity programming after 60 seconds, timer will return to clock default *Timer will hold existing program for 60 seconds while the batteries are being changed.</p>	<p>*Minimum of 10 psi is required, maximum of 85 psi. *Remove timer from water source in freezing temperatures. *Water flows from the female end thru to the male end. Do not install backwards as this will void the warranty. *For outdoor use with clean, cold water only. * With hard water, extra filtration may be needed.</p>
<p>Manual Open and Close: Press ON key, the water valve will open, LCD will display . Press OFF key to turn off.</p> <p>A: SET CURRENT TIME </p> <ol style="list-style-type: none"> 1. Press Set Clock, LCD will display 2. "Hour" blinks, then press +/- to set hours, press set clock to move to minutes. Pressing the hour button moves the time from AM to PM 3. "Minutes" blinks, then press +/- to set minutes, press set clock to move to seconds 4. "Seconds" blinks, then press +/- to set seconds, press set clock 5. Set Day of the week by pressing +/- 7. Press return arrow to return to standard operating mode. <p>B. SET PROGRAM/S (1-9) </p> <ol style="list-style-type: none"> 8. Press Set Mode, LCD will display with a flashing program number 9. Press +/- to set which program you wish to set, press set clock 10. Set the ON/Off box to ON by using the +/- buttons, then press set mode (Make sure all unused programs are in the "off" mode) <p>C. WATER ON TIME (AMOUNT OF TIME YOU WISH THE TIMER TO BE ON) </p> <ol style="list-style-type: none"> 12. "Hour" blinks, then press +/- to set hours, press set clock to move to minutes 13. "Minutes" blinks, then press +/- to set minutes, press set clock to move to seconds 14. "Seconds" blinks, then press +/- to set seconds, then press set mode 	<p>D. WATER OFF TIME (AMOUNT OF TIME YOU WISH THE TIMER TO BE OFF) </p> <ol style="list-style-type: none"> 15. "Hour" blinks, then press +/- to set hours, press set clock to move to minutes 16. "Minutes" blinks, then press +/- to set hours, press set clock to move to seconds 17. "Seconds" blinks, then press +/- to set seconds, then press set mode <p>E. PROGRAMMING DAYS </p> <ol style="list-style-type: none"> 18. Press set clock to select days of the week. Days displayed are "ON" days. Days not displayed are off days. (Use +/- to turn on or off the days of the week.) Press set mode when finished programming days. <p>F. SET START TIME (TIME YOU WANT YOUR PROGRAM TO START) </p> <ol style="list-style-type: none"> 19. "Hour" blinks, then press +/- to set hours, press set clock to move to minutes. Pressing the hour button moves the time from AM to PM 20. "Minutes" blinks, then press +/- to set minutes, then press set mode <p>G. SET OFF TIME (TIME YOU WANT PROGRAM TO STOP) </p> <ol style="list-style-type: none"> 21. "Hour" blinks, then press +/- to set hours, press set clock to move to minutes. Pressing the hour button moves the time from AM to PM 22. "Minutes" blinks, then press +/- to set minutes 23. Press back arrow to complete program, or press the next number to start the next program.

Warranty: 1 year limited warranty for any defect arising under normal use and service under the warranty period. Return the timer to the place you purchased the product. You must have the original receipt. Provide the retailer with detailed information, for a replacement or refund at retailer's discretion. The replacement will be covered for the remainder of the warranty period dating from the original purchase. Freezing or damage to the timer voids all warranty.

Visit www.mrsoakerhose.com for any additional information.

See You Tube video for programming: http://www.mrdrip.com/549--Mist-Timer-II--Times-in-Seconds-_p_996.html