


Instruction for Digital Water Flow Gauge

Model: AF-012 52212



Your Digital Water Flow Meter – Professional Series comes to you with battery already installed and it will measure up to 999.9 litres/gallons.

Button A: Clear - 1) Back to zero for each watering session

Button B: Reset - 1) Back to zero for Accumulated Water Usage

The LCD displays will flash once after inserting battery, then screen appears as above.

The default measurement is GAL (Gallon)

To start counting function from battery save mode:

1) Press button A or B (or both A & B)

2) The device will detect any water flow and start to count.

Battery save mode: The screen will fade out in 30 minutes if there is no water flow or no button activation.

Operation

1) When water flow commences, both (E) and (W) will count the flow volume (fig 1).

2) To zero (E) reading, press button A. (fig 2).

3) (W) reading continues to accumulate water volume (fig 3) until zeroed.

4) To take both (E) and (W) back to zero press button B.

How to switch measurement (Litre/Gallon) - Easy to change the volume unit from liter to gallon

Press button A for three seconds and release. A dark point on left will flash (fig 4).

Select GAL or LIT by pressing button B and press button A to confirm setting

In this mode, the flow meter counter will revert to counting function in 30 seconds if no button is pressed.



fig1

fig 2

fig 3

fig 4

To exchange battery:

1) Remove the back cover with a coin.

2) Exchange new battery of type CR2032.